

MODEL

R12000 (HW) or REDWOOD (HW) (DRY or with FAN) For Australia

INSTALLATION SPECIFICATION SHEET

These instructions must be used in conjunction with the 'General Installation Instructions' for Masport wood fires.

Important Note: Masport R12000/REDWOOD model needs to be installed with specific flue shield, flue divertor plate and/or ceiling plate. The Glen Dimplex warranties will void unless fitted with these components.


Refer instruction sheet 583575 for detailed instructions to fit these shielding components.

CLEARANCE REQUIREMENTS


This fire has been tested and complies to the Australian/New Zealand Standard AS/NZS 2918:2001 and all installations must be in accordance with the minimum clearances to combustibles indicated in these instructions.

The minimum clearances to combustables may be reduced if the combustable walls are shielded with an approved non-combustable material. Details of suitable materials and appropriate clearance reduction factors are present in Section 3 of AS/NZS 2918:2001.

POSITIONING YOUR FREE-STANDING WOODFIRE







CORNER INSTALLATION

AUSTRALIA

MINIMUM DISTANCES TO HEAT SENSITIVE WALLS (mm)

MODEL	FLUE SYSTEM & FLUE SHIELD	Α	В	E	F	G	Н	R§
R12000 or REDWOOD (Dry or with Fan)	FLOMET UNIVERSAL FLUE SYSTEM + MASPORT 850mm SINGLE SKIN SHIELD		500	240	413	895	630	891
	AIR-GROUP SPECIAL INSULATED FLUE + MASPORT 900mm DOUBLE FLUE SHIELD + TOP DIVERTER PLATE + 500x500 CEILING PLATE		500	240	438	895	630	891

§ Valid only when the room walls are at 90° to each other.

‡ Note: Clearances are for fire hazard only. For durability of finishes or surfaces you should contact the relevant manufacturer for their specification. Masport accepts no responsibility for the deterioration of surfaces or finishes.


* Air-Group Special Insulated Flue Kit is same as AHD Special Insulated Flue Kit

PRT. NO. 583573

DATE: 09.10.2017

FLOOR PROTECTOR (Hearth) REQUIREMENTS PARALLEL INSTALLATION

MINIMUM FLOOR PROTECTOR DIMENSIONS IN mm



AUSTRALIA - ALL WITH FLUE HEATSHIELD

MODEL	Flue Shield	Floor Protector height	A #	C#	D	F	I	J	K#	P2	Р3	W	Floor Protector Type Ø
R12000 or REDWOOD (Dry or with Fan)	FUF	ANY	213	300	87	413	664	964	1133	620	200	790	AFP
	AGA	ANY	238	300	87	438	664	964	1158	620	200	790	AFP

FUF = FLOMET UNIVERSAL FLUE SYSTEM +_ 850mm Single Flue Shield

AGA = AIR GROUP / AHD SPECIAL INSULATED FLUE KIT + SPECIAL 900mm DOUBEL FLUE SHIELD +

TOP DIVERTER PLATE + 500x500 CEILING PLATE


AFP = ASH FLOOR PROTECTOR

Ø for minimum constructional requirements see general installation instructions.

Dimensions in table are valid only when the fire is exactly at its minimum allowable wall clearance.

FLOOR PROTECTORS (Hearth) REQUIREMENTS CORNER INSTALLATION

MINIMUM FLOOR PROTECTOR DIMENSIONS IN mm



DIMENSIONS IN THE TABLE ARE VALID ONLY WHEN THE FIRE IS EXACTLY AT ITS MINIMUM ALLOWABLE WALL CLEARANCE.

AUSTRALIA

MODEL	Flue Shield	Floor Protector Distance above Floor	С	E	Н#	L#	М#	N	R#	FLOOR PROTECTOR TYPE
R12000 or REDWOOD (Dry or with Fan)	FUF	ANY	300	240	630	1611	1374	720	891	AFP
	AGA	ANY	300	240	630	1611	1374	720	891	AFP

FUF = FLOMET UNIVERSAL FLUE SYSTEM + 850mm Single Flue Shield


AGA = AIR GROUP / AHD SPECIAL INSULATED FLUE KIT + SPECIAL 900mm DOUBEL FLUE SHIELD +

TOP DIVERTER PLATE + 500X500 CEILING PLATE

AFP = ASH FLOOR PROTECTOR

Dimensions in table are valid only when the fire is exactly at its minimum allowable wall clearance.


FREE STANDING FIRE DIMENSIONS



MODEL	P1	P3	Н	W	S1	S2	S3	S4
R12000 or								
REDWOOD	623	200	798	790	340	170	20	615
(Dry or with Fan)								

<u>Seismic Restrain</u> - In New Zealand and some part of Australia, it is required that the wood fire and floor protector are secured to prevent shifting in the event of an earthquake. This is best done by fastening the wood fire right through the protector to the floor, using two 8mm dynabolt or 8mm coach screws or toggle fasteners for wooden floors of appropriate length.

THIS FLUE INSTALLATION DIAGRAM BELOW IS VALID FOR AUSTRALIAN INSTALLATIONS WITH AIR GROUP SPECIAL INSULATED FLUE KIT SUPPLIED BY AIR GROUP.



THIS FLUE INSTALLATION DIAGRAM BELOW IS VALID FOR AUSTRALINA INSTALLATIONS WITH UNIVERSAL FLUE SYSTEMS SUPPLIED BY FLOMET.

